



Material releases floor

Heating foil E-NERGY CARBON FLEECE

Caution: Install E-NERGY CARBON according to the installation instructions. Only use plastic spatula to press in the heating foil. Avoid kinks and folds. After installing the heating foil, a complete covering layer (filler, plaster system, tile, etc.) of at least 2 mm must be applied. Use recommended products in accordance with the manufacturer's instructions and the generally recognised rules of technology. TIP: Check in the manufacturer's instructions when the heating system can be put into operation. In the case of tile coverings, this can take up to 28 days.

Parquet	
Universal primer UZIN PE 360 PLUS	
Premium levelling compound UZIN NC 170 LevelStar	
-	
1. Bonding the heating foil with UZIN PE 630 / UZIN PE 650 2. Levelling on the heating foil with Premium levelling compound UZIN NC 170 LevelStar	
+	
-	
ring UZIN MK 250 / UZIN MK 92 S	

Textile / elastic floor coverings	Textile coverings / needlefelt	PVC/CV coverings Design coverings	
Primer	Universal primer U	Universal primer UZIN PE 360 PLUS	
E Compensation	Premium levelling compound UZIN NC 170 LevelStar		
Compensation Primer on balance	Universal primer UZIN PE 360 PLUS		
Embedding heating foil	 Bonding the heating foil with UZIN PE 630 / UZIN PE 650 Levelling on the heating foil with Premium levelling compound UZIN NC 170 LevelStar 		
Primer on embed- ded heating foil	-		
Adhesive coating	Textile flooring: UZIN UZ 88 PVC/CV coverings: UZIN KE 66 PVC Designbeläge: UZIN KE 66 Linoleum: UZIN LE 44		